




Sending message to the phone:

1. Go to <https://satellitesos.com/sendMessage.php>
2. Choose network and enter phone number
3. Write your text
4. Write sender address for easy reply
5. Send message



Short manual

Iridium Extreme

Call from the phone

1. Type phone number

Numbers should be in international format
Example +46775888191

2. Press call (green button)

Calling to the satellite phone

1. Call +881 and the phone number
 Example +881641400566
2. FREE test call
 +14807525151

Send text message

Send text as SMS or EMAIL

1. Go to "Menu"
2. Choose "Messages"
3. Choose "Create Message"
4. Write your text
5. "Options"
6. "Send"
7. choose "Add " and then you can choose from contacts or enter new recipient
8. click" Send"

If you have any problem, contact us:

+46775888191

Save contacts, Call or send text messages to your contacts

Go to My Phonebook in the menu

1. Choose Select
2. Choose your option
 - a. New contact
 - b. Call
 - c. SMS
 - d. Delete
3. Follow the instructions on the screen

Check messages in Inbox/outbox

1. Go to Menu
2. Messages
3. Inbox/outbox